ARM ISA

Friday, March 23, 2018 3:27 AM

1. LDUR

I. Instruction - D Format

| 301111000010 (11) 3010 100011 3010 100011 | 00111000010 (11) | 9bit-Addr | 00 | 5bit-BaseReg# | 5bit-Reg# |
|---|------------------|-----------|----|---------------|-----------|
|---|------------------|-----------|----|---------------|-----------|

II. Action: RegFile[Reg#] <= DM[9bit-Addr + RegFile[BaseReg#]]</pre>

2. STUR

I. Instruction - D Format

| 00111000000 (11) 9bit-Addr 00 5bit-BaseReg# 5bit-R |
|--|
|--|

II. Action: DM[9bit-Addr + RegFile[BaseReg#]] <= RegFile[Reg#]</p>

3. ADD

I. Instruction - R Format

| 10001011000 (11) | 5bit-Reg1# | 000000 | 5bit-Reg2# | 5bit-DestReg# |
|------------------|------------|--------|------------|---------------|
| | | | | |

II. Action: RegFile[DestReg#] <= RegFile[Reg1] + RegFile[Reg2]</p>

4. ADDI

I. Instruction - I Format

| 1001000100 (10) 12bit-Immed# | 5bit-Reg1# | 5bit-DestReg# | |
|------------------------------|------------|---------------|--|
|------------------------------|------------|---------------|--|

II. Action: RegFile[DestReg#] <= RegFile[Reg1] + Immed#

5. SUB

I. Instruction - R Format

| 11001011000 (11) | 5bit-Reg1# | 000000 | 5bit-Reg2# | 5bit-DestReg# |
|------------------|------------|--------|------------|---------------|
|------------------|------------|--------|------------|---------------|

II. Action: RegFile[DestReg#] <= RegFile[Reg1] - RegFile[Reg2]</p>

6. AND

I. Instruction - R Format

| 10001010000 (11) 5bit-Reg | 1# 000000 | 5bit-Reg2# | 5bit-DestReg# |
|---------------------------|-----------|------------|---------------|
|---------------------------|-----------|------------|---------------|

II. Action: RegFile[DestReg#] <= RegFile[Reg1] & RegFile[Reg2]</p>

7. ORR

I. Instruction - R Format

| 10101010000 (11) 5bit-Reg1# 000000 5bit-Reg2# 5bit-DestReg# | |
|---|--|
|---|--|

II. Action: RegFile[DestReg#] <= RegFile[Reg1] | RegFile[Reg2]</p>

8. CBZ

I. Instruction - CB Format

| 10110100 (8) | 19-bitAddr | 5bit-CheckReg# |
|--------------|------------|----------------|
| 10110100 (8) | 19-bitAddr | Sbit-Checkkeg# |

II. Action: PC <= (RegFile[CheckReg#]) ? PC+4: PC+Addr

9. CBNZ

I. Instruction - CB Format

| 10110101 (8) 19-bitAddr 5bit-CheckReg# |
|--|
|--|

II. Action: PC <= (RegFile[CheckReg#]) ? PC+Addr : PC+4

10. B

I. Instruction - B Format

```
000101 (6) 26bit-Addr
```

II. Action: PC <= PC+Addr

11. TRAP

I. Instruction - TRAP Format

II. Action: Halt (End Program/ Stop Machine)

